

Bleach cleanable Stain resistant

Antibacterial





Stain resistant | Bleach cleanable | Antibacterial

Catalina is aniline-dyed in the drum and given a full-protection finish highlighted by a distinctive pebble grain and soft sheen. With its exclusive Crypton® finish it is durable and well-priced, making it ideally suited for applications in healthcare, hospitality, contract and other high-traffic applications. Catalina is made in the USA and is stocked in more than 25 colors.

Environmental Stewardship: Catalina is produced in a tannery which has achieved a gold rating as audited to the Leather Working Group environmental stewardship and traceability standards. Further enhancing its sustainability profile, Catalina is finished without the use of solvents or lead, emits low VOCs and has achieved an Indoor Gold Advantage certificate from SCS.

Technical Specifications

Origin

Raw Material

Leather Type

Hide Size

Thickness

Abrasion Resistance

Light Fastness

Wet Crocking

Dry Crocking

Blocking

Elongation

Tear Strength

Flexibility

Antibacterial

Stain Release

Flame Resistance

Performance Category Cleaning Code

USA

Top grain, aniline drum dyed

Pigmented, powered by Crypton®

48 - 52 sq.ft.

1.0 - 1.2 mm

ASTM D7255: CS10 Wheel Taber 1,000 Cycles/1,000 gram weight

ISO 102-B05: Blue Wool Scale ≥ 5

ASTM D5053: Class 5

AATCC 8 and ASTM D5053: Class 4 or better

TMS 311 3121.1: Separate with ease and no finish damage

ASTM D2208: 40% maximum at 100 lbs.

150 3377: 100 lb. minimum

ASTM D2097: 70,000 cycles

AATCC 100: 99.9% Reduction of Bacteria - AATCC 4352 Klebsiella Pneumoniae

and AATCC 6538 Staphylococcus Aureus

AATCC 130-2000: 5 Rating (Excellent) for Coffee, Wine, Ketchup, Hair Products, Sunscreen, Betadine and Body Fluids; Withstands a 5% bleach solution

NFPA 260: Class 1; CAL TB117-2013; Boston Fire Code; NY/NJ PortAuthority; FMVSS 302; IMO 2010 FTP Part 8 (A.652(16))

3

5

















Available Colors



Performance Category 3

Leathers with Performance Category 3 are protected for use in the most challenging wear, stain and fading environments such as commercial aviation, automotive, office task chairs and dining seating. Only pigmented and Semi-aniline leathers with strong protection meet the standards for this category. Of course, these leathers are also suitable for any application where bright, uniform colors and exotic looks are desired. Several Performance Category 3 leathers have additional Crypton® protection. More information is available on our website at cortinaleathers.com/resources/performance/ and at cortinaleathers.com/resources/crypton/.

Care & Cleaning Code 5

Cortina Leathers with Crypton® provide the industry's greatest stain resistance and cleanability. Stains which can be easily removed include wine, coffee, sunscreen, hair gel, hair mousse, vinegar, blood, urine and most other stains from food and typical soiling. Should a spill occur, blot (pressing gently without rubbing) immediately using clean, dry sections of an absorbent cloth or paper towels. Should soiling remain or for a more thorough cleaning, Cortina Leathers Universal Cleaner High-Tech Wipes® or a solution of lukewarm water and a mild cleaner, such as Ivory® soap or Woolite®, may be used. Dampen a clean white cloth and gently wipe the affected area using a circular motion. Rinse completely with clean sections of cloth which is damp with plain water until all cleaner is



New York, New York
Conneaut, Ohio
samples@cortinaleathers.com
office: 800-338-6229
cortinaleathers.com



Care & Cleaning Code 5 (continued)

removed. Blot dry with paper towels or dry cloth and allow to completely air dry. Repeat the cleaning process as needed, allowing the leather to dry between applications. If necessary, Cortina's running-line Crypton protected leathers can be cleaned with cleaners containing up to a 5% bleach solution (Sodium Hypochlorite). However, most stains can be easily removed using just gentle soap and water or the readily available commercial and household cleaning products listed on our website.

Note: To ensure complete removal of any stain from Crypton-treated leathers, the cleaning process must be undertaken within 60 minutes of any spillage or staining occurring. Successful stain removal will become less possible over time, so always treat spills and stains immediately. Avoid the excessive application of cleaning products on seams or stitching. Visit cortinaleathers.com/resources/care-cleaning/ for more information.

Warranty

Leathers with Performance Category 3 have a 5 year limited warranty against manufacturing defects. Leathers with Crypton protection also feature a 3 year warranty for stain resistance. See complete details at cortinaleathers.com/resources/warranty/.



New York, New York
Conneaut, Ohio
samples@cortinaleathers.com
Office: 800-338-6229

cortinaleathers.com